



HOW TO CALCULATE STARTER STRIP PANELS FOR TRADITIONAL STYLE



FLAT PANEL




CORNER PANEL



STARTER STRIP PANEL

Starter Strip Panels are used as the first course at the base of the wall in combination with the Flat Panels. Starter Strip Panels are also used as the first course above window and door openings.




Step 1

Measure the total linear feet of the horizontal base of the wall to be covered in stone. Multiply this number by 12 to convert it to inches.




Step 2

Divide the total by 2, as a Starter Strip Panel is required for every other panel. This will give you the total length of Starter Strip Panels required.



Step 3

Divide the total length by 21.25 inches, as this is the length of a Starter Strip Panel. This will give you the total number of Starter Strip Panels required.



Step 4

Divide the total number of Starter Strip Panels required by 8, as there are 8 panels in a box. This will give you the total number of boxes required.

TOTAL LENGTH OF STARTER STRIP PANELS REQUIRED = (TOTAL LENGTH OF THE WALL IN LINEAR FEET ÷ 2) × 12 INCHES/FOOT
QUANTITY OF STARTER STRIP PANELS REQUIRED = TOTAL LENGTH OF STARTER STRIP PANELS REQUIRED ÷ 21.25 INCHES
TOTAL QUANTITY OF BOXES REQUIRED = QUANTITY OF STARTER STRIP PANELS REQUIRED ÷ 8



LEARN MORE ABOUT TIER® NATURAL STONE BY CONTACTING YOUR LOCAL REP OR CUSTOMER SERVICE

T: 1.800.977.8663 W: www.AllThingsStone.com

Proudly Distributed By



All things Stone ... and more

